

Overview





With our Pinware 4 software, you can easily create and mark text, serial/date codes, graphics and 2D barcodes.

This feature packed software runs directly on our UMC Eco, or UMC 112 controllers. The Pinware 4 software can also run on your Windows XP/2000 PC in conjunction with our UMC Box.

With an intuitive menu-driven interface, a "what you see is what you get" display, and "teach-in" alignment feature you can create new part marking programs in seconds. Take our software for a test drive; visit the downloads section at our website www.permanentmarking.com today to see how easy it is!

Features



- **Intuitive Menu Driven**
- **Marks text, serial/date codes, graphics, and 2D codes**
- **Character Height Programmable from .1 to 99 mm**
- **Character Spacing Programmable from 0 to 10 mm**
- **Character Width Programmable from .1 to 10 mm**
- **Barcode scan data entry**
- **Date/Time/Shift/User Defined Codes**
- **Integrated software SPS for custom applications**
- **Easy File Storage????**
- **31 Text Fields available with 50 characters each**
- **2D Code (Data matrix)**
- **Teach-in text and field positioning**
- **Import of HPGL plotting files (.plt)**

With the Pinware software creating a new marking file is simple. Just type in the text, define placement and orientation, press the preview button to confirm the mark, and press start!